



Please check the switch for the correct configuration before installation.

The contact blocks on the BSTHD1022 switch are custom configured from the factory. Sometimes they arrive in the standard configuration and will need to be modified to work properly.

Standard Configuration



Flip the end contact 180deg



The correct configuration looks like this:

